GreaseShield - Daily Maintenance



DO NOT ACCESS THE INSIDE OF THE GREASESHIELD!

DO NOT USE THE TOP OF THE GREASESHIELD AS A SHELF!



EMPTY AND CLEAN Fats, Oils and Grease collection container DAILY. Grease should be collected by authorised waste colectors.



CLEAN WIPER BLADE on FOG collection container.



EMPTY and CLEAN solids waste collection container daily. Solid waste can go for composting!



Use an IP56 socket (splash and dust proof). A damaged supply cord must be replaced by the manufacturer or a qualified electrician.



The GreaseShield needs to be SERVICED REGULARLY. Maintenance Contracts are available!

Contact EPS on +44(0) 2830 833 081

The ONLY self-cleaning greasetrap in the world!

Contact EPS on +44 (0) 2830 833 081 or email Info@ProtectingTheEnvironment.com

